



PrimeDTV
Universal Remote Control
Model: PHD-UR58

User Manual

Congratulations! You now have a PrimeDTV Universal Remote Control that will control four devices including a PrimeDTV Receiver Box, TV and other two devices.

Before using your PrimeDTV Universal Remote Control, you may need to program it to operate with your particular devices. Please follow the instructions in this guide to set up your remote control and enjoy it!

A、 Direct Code Entry

- 1、 Locate the code list provided in this manual. First find the device you wish to program and then find the brand name for that device.
- 2、 Press and hold the **SET** button (approximately 3 seconds) until the red indicator light stays on and release.
- 3、 Press and release the desired device button (TV, DVD, STB or AUX) on the remote.
- 4、 Enter the first set of 4-digit code previously found in the code list by using the number buttons on the remote. The red indicator flashes once when each digit entered. If the 4-digit code entered is valid, the red indicator light will be turned off. Otherwise, if the code entered is not valid, the red indicator light will

flash twice and remain on allowing you to re-enter the new code. If no buttons were pressed for 35 seconds, the remote will exit the setup procedure and you will need to start over.

B、 Auto code search

- 1、 Press and hold the **SET** button (approximately 3 seconds) until the red indicator light stays on and release.
- 2、 Press and release the desired device button (TV, DVD, STB or AUX) on the remote.
- 3、 Point the remote to the device, then press and release the **POWER** button to start searching. The red indicator will flash (approximately every 2 seconds) as the remote searches. The remote must be pointed to the device during this code searching procedures. When auto search is completed, the red indicator will flash 1 second then turn off.
- 4、 During auto code search, you can press **SET** button to change the code search direction.
- 5、 During auto code search, you can press any function keys to save the current code and exit the auto code search mode.

C、 Manual code search

- 1、 Press and hold the **SET** button

(approximately 3 seconds) until the red indicator light stays on and release.

- 2、 Press and release the desired device button (TV, DVD, STB or AUX) on the remote.
- 3、 Press the **CH+** button. The device key flashes to indicate the search mode is started and ready to search.
- 4、 Press the **CH±** button to change search directions. Press the **POWER** button to test the code manually and to see if the remote turns the device on or off successfully. The red indicator will flash 1 second and turn off when the search is finished.
- 5、 Press the desired device button or no buttons were pressed for 35 seconds, then the current code will be saved and the search is stopped. If other device buttons were pressed during the searching, the search mode will be stopped and no code will be saved.

=====

The Volume and Mute buttons can be controlled by each individual device or by one main device only. To control by one main device like TV, you need to lock the Volume and Mute buttons to the desired device. Otherwise, unlock the Volume and Mute buttons so every device can have its own control of adjusting volume and mute.

D、 Lock Volume and Mute

- 1、 Press and hold the **SET** button (approximately 3 seconds) until the red indicator light stays on and release.
- 2、 Press and release the device button, which the volume and mute need to be locked.
- 3、 Press and release the **MUTE** button.
- 4、 Press the **VOL+** button and the red indicator light will flash twice and turn off. This will lock the volume and mute to the desired device only.

NOTE: In normal operation, when you press **VOL±** or **MUTE** button, which is already locked to the other device, then other device red indicator light will flash once first followed by the current device red indicator light.

E、Unlock Volume and Mute

- 1、 Press and hold the **SET** button (approximately 3 seconds) until the red indicator light stays on and release.
- 2、 Press and release the **MUTE** button.
- 3、 Press the **VOL-** button and the red indicator light will flash twice and turn off.

F、Reset

- 1、 Press and hold the **SET** button (approximately 3 seconds) until the red indicator light stays on and release.
- 2、 Press and release the **OK** button.

- 3、 Press and hold **0** button until the red indicator of TV device blinking 3 times to reset the remote.

G、 Shift Function

- 1、 Shift function :

Normal	CH+	CH-	VOL+	VOL-	MUTE	BACK	INFO
Press SET	UP	DOWN	RIGHT	LEFT	OK	EXIT	MENU

- 2、 The Normal function buttons will be used during the normal operation mode.

- 3、 Press **SET** button once as red indicator flashing, the shift function will be used for these buttons shown in the table. If no buttons were pressed for 10 seconds after that, the remote will exit the shift function and back to the normal mode.

- 4、 To toggle the **SET** button, the remote will switch between Normal function and Shift function mode.



1. In normal operation, press any function buttons, the device red indicator light will be lite up to indicate which current device is selected. To switch to other device, simply press the desired device key once to switch to.

Brand Code List

TV

BRAND	TV
Abex	5011,5286
Accurian	5140,5452
Accuscan	5005,5014
Acme	5156
Action	5002,5006,5010,5042
ADA	5167
ADC	5152,5154
Admiral	5003,5004,5005,5014,5015 ,5018,5025,5035,5040,504 1,5055,5165,5308,5455
Advantz	5049
Advent	5030,5080,5087,5094,5101 ,5238,5326 ,5456,5457
Adventura	5279
Adventuri	5001
Adyson	5011
Agna	5030
Aiko	5024
Aiwa	5011,5295,5296,5309
Akai	5010,5012,5020,5021,5028 ,5031,5064,5071,5149,521 1,5230,5361,5362,5372,53 73,5410,5442
Alaron	5037,5040
Alba	5011,5012,5045

Albatron	5002
Alfide	5064
Alleron	5010,5037,5193
Amark	5002,5007,5011,5013,5014 ,5018,5035,5165
Ambassador	5030,5039
America Action	5041
American High	5001,5021
Ampro	5079
Amstrad	5013,5038,5039
Amtron	5001,5041,5062
Anam	5041
Anamnational	5019,5062,5150,5169,5184 ,5293
AOC	5002,5006,5010,5011,5012 ,5013,5041,5042,5151,515 2,5155,5159,5264,5280,52 88,5341,5429,5439,5461,5 476
Aomni	5399
Apex	5078,5081,5113,5321,5367 ,5423
Apex Digital	5033,5042,5078,5081,5083,5 113
Archer	5002,5165
Aspect	5198
Astar	5472

Asuka	5045
Audinac	5041
Audio-Technica	5006
Audiovox	5002,5024,5040,5041,5054 ,5061,5062,5074,5090,511 2,5140,5147,5348,5436,54 57
AUVIO	5451,5489
Aventura	5038
Axion	5147,5281,5454
Bang&Olufsen	5291
Basicline	5045
Baycrest	5011,5043
Baysonic	5041
Beaumark	5004,5006,5010,5040
Belcor	5006,5010,5151
Bell&Howell	5003,5018,5025,5032,5040 ,5133,5191
Benq	5139,5215,5226,5383,5462
Bluesky	5258,5386
Boxlight	5118
Bradford	5041,5062
Brick	5013
Brockwood	5006,5010,5020
Broksonic	5002,5013,5039,5041,5046 ,5055,5142,5253,5315,532 0,5458,5459
Brokwood	5151

Candle	5010,5013,5020,5043,5151 ,5155,5279
Capehart	5002,5004,5006,5010,5011 ,5024,5280
Carnivale	5010
Carver	5018,5037
CCE	5122
Celea	5081
Celebrity	5001,5149
Celera	5081
Centrios	5274
Centurion	5155
Cetronic	5184
Changhong	5033,5081,5083,5087,5321
Cinego	5016
Cineral	5024,5054,5258
Citek	5011,5014
Citizen	5001,5002,5003,5006,5007 ,5010,5011,5013,5018,502 0,5021,5024,5038,5041,50 43,5048,5049,5054,5055,5 062,5127,5151,5155,5184, 5230,5253
Civet	5042
Clairtone	5042,5159
Clarion	5041
Classic	5006,5010,5020,5024,5081 ,5184,5321
COBY	5359,5364,5463,5464

Color voice	5156
Coloryme	5004,5005,5006,5010,5011 ,5014,5018,5021,5151,5155,5156
Colt	5006
Commercial solutions	5014,5133
Concerto	5020,5151,5155
Conic	5006
Concierge	5235
Contec	5041,5042,5052,5159,5184 ,5062
Cornea	5192
Craig	5038,5040,5041,5049,5184 ,5062
Crosley	5001,5010,5018,5026,5038 ,5041,5044,
Crown	5013,5020,5025,5041,5062 ,5064,5184
Crownmustang	5064
CTX	5165
Curtis Mathes	5001,5003,5005,5006,5010 ,5011,5012,5013,5014,5015,5018,5020,5021,5025,5028,5032,5036,5040,5041,5054,5056,5071,5077,5124,5127,5131,5133,5151,5155,5160,5191,5230,5249,5318, 5460

CXC	5041,5184,5062
Cybervision	5258
Daewoo	5006,5007,5013,5024,5054 ,5061,5064,5064,5138,513 9,5151,5152,5155,5156,51 62,5163,5164,5181,5184,5 185,5213,5225,5246,5247, 5249,5256,5324
Dayton	5024,5151,5155
Daytron	5006,5010,5011,5013,5020 ,5024
Dell	5006,5122,5134,5172,5251,5 390
Denon	5012,5019,5028,5060
Denstar	5062
Diamond Vision	5220,5304,5331
Digimate	5346
Digistar	5078,5087,5238,5251,5270,5 272,5348,5384,5385
Digital Lifestyles	5479
Digital Stream	5453
Dimensia	5133
Disney	5253,5265
Dukane	5198,5066
Dumont	5003,5004,5006,5011,5041 ,5151,5235

Durabrand	5002,5006,5038,5041,5055,5120,5253,5262,5290,5307,5370
Dwin	5025,5077,5085
Dynasty	5184
Dynex	5421
Eaton	5021
Electroband	5001,5042,5149,5159
Electrograph	5138
Electrohome	5001,5006,5010,5011,5013,5020,5030,5031,5032,5042,5052,5150,5151,5155,5167
Elektra	5003,5004,561
Elite	5045
Elite Video	5297
Emerald	5006,5039
Emerson	5006,5011,5012,5013,5014,5029,5030,5032,5037,5038,5039,5040,5041,5042,5046,5048,5049,5054,5055,5061,5062,5141,5142,5155,5166,5168,5169,5171,5174,5175,5176,5177,5179,5181,5182,5183,5184,5186,5187,5191,5193,5249,5253,5282,5290,5304,5309,5310,5313,5315,5325,5509

Envision	5006,5010,5011,5013,5092 ,5151,5155,5341
Epson	5097,5100
ESA	5038,5071,5290
Fisher	5001,5018,5032,5034,5052 ,5191,5234,5034
Flex Vision	5074
Fortress	5025
Fujitsu	5040,5043,5067,5091,5105 ,5193,5297,5338
Funai	5001,5013,5038,5040,5041 ,5062,5141,5184,5193,529 0,5309,5325
Futuretec	5184,5062
Futuretech	5041
Gateway	5138,5139,5188
GE	5001,5005,5006,5008,5010 ,5012,5014,5015,5019,502 1,5049,5054,5077,5124,51 31,5133,5144,5150,5151,5 155,5160,5167,5186,5194, 5218,5232,5245,5190,5317
Gemini	5014
Gibraltar	5001,5004,5006,5010,5151 ,5235
Go Video	5116
Go Vision	5147

Goldstar	5005,5006,5010,5011,5013 5014,5018,5020,5052,5106,5151,5152,5155,5197,5213,5264,5309,5316
Goodmans	5050
GPX	5040
Gradiente	5017,5020,5037,5151,5238 5262,5344,5389
Grandtec	5480
Granprix	5040
Granada	5011
Grundig	5064,5067,5072
Grundy	5040,5041,5062,5193
Grunpy	5040,5041
Guestvision	5299
Gvision	5337
Haier	5078,5120,5139,5307,5380 5409,5432
Hallmark	5006,5040,5041,5044,5046 5151,5155
Hannspree	5132
Harley-Davids on	5001,5006,5010,5021,5040 5041,5141
Harman/Kard on	5018
Harvard	5041,5062
Hauppauge	5403
Havermy	5025

Heathkit	5004
Helios	5110
Hellokitty	5054
Hewlett-Packard	5336,5465,5481
Hikone	5045
Himitsu	5041,5062,5086
Hisense	5078,5209,5284,5345
Hitachi	5001,5003,5004,5005,5011,5012,5013,5014,5015,5018,5019,5020,5028,5031,5040,5042,5052,5066,5123,5141,5151,5155,5198,5199,5200,5254,5255,5257,5282,5309,5334,5437,5448
Hyundai	5103,5110,5369,5466,5467
ILO	5259,5290,5298,5351,5357,5362,5408,5413
IMA	5006,5040,5041,5046,5062
InFocus	5133
Infinity	5018,5314
Initial	5259,5357
Insignia	5038,5173,5228,5238,5252,5253,5272,5290,5307,5325,5381,5417,5420
Integra	5283
Inteq	5004,5028,5235
Janeil	5279
JBL	5018

JC Penney	5008,5043,5052,5127,5133 ,5151,5152,5155,5160,5167,5174,5194,5218,5230,5232
JCB	5001,5149
Jensen	5030,5080,5094,5151,5155,5252
JIL	5006,5010
Jutan	5006,5010
JVC	5010,5017,5018,5019,5052 ,5076,5170,5199,5203,5204,5206,5257,5266,5297,5311,5327,5434,5449
Kamp	5004,5006,5041,5042
Kawasho	5006,5010,5042,5149,5151 ,5155
Kaypani	5280
KEC	5021,5041
KEC0041	5062
Kenmore	5029
Kenwood	5006,5010,5041,5151,5155
KLH	5033,5041,5081,5083
Kloss	5009,5010
Kloss Novabeam	5205,5279
KMC	5002,5011
Kogi	5337
Konka	5041,5045,5062,5073,5157,5161,5173,5189,5228,5322

KTV	5010,5013,5041,5042,5048 5055,5062,5159,5166,518 4,5207
Kurazai	5003
Lark	5032
Lasonic	5304,5331
Legend	5238
LG	5002,5006,5010,5018,5020 5021,5052,5106,5107,512 8,5151,5152,5155,5192,51 97,5213,5251,5263,5264,5 309,5316,5392, 5483
Liquidvideo	5273,5281
Lloyd's	5010,5011,5013,5020,5040 5041,5046,5141
Lodgenet	5003,5133,5300
Loewe	5027,5018,5305,5485
Logik	5003,5020,5040,5041,5046 5133
Luce	5195
Luxman	5020,5151,5155
Lxi	5001,5003,5004,5005,5006,5 007,5008,5009,5010,5011,50 12,5013,5014,5015,5017,501 8,5019,5020,5021,5025,5026 5029,5032,5033,5034,5035, 5036,5038,5040,5048,5077,5 127,5133,5151,5155,5160,51 91,5232,5309

Macy	5013,5043
Magnasonic	5001,5002,5006,5010,5018 ,5020,5024,5025,5033,504 0,5141,5193
Magnavox	5001,5006,5007,5009,5010 ,5014,5015,5018,5021,502 4,5026,5032,5038,5040,50 41,5043,5044,5047,5049,5 051,5072,5090,5101,5134, 5138,5141,5151,5155,5205 ,5210,5257,5285,5308,531 4,5325,5368,5411
Majestic	5003,5004,5133
Marantz	5010,5018,5031,5106,5134 ,5151,5155,5283
Matsui	5013,5020,5039
Matsushita	5015,5047,5063
Maxent	5138,5139,5188
Medion	5265,5277,5298
Megapower	5002
Megatron	5002,5006,5014,5020,5028 ,5031,5151,5155,5198
Mei	5042,5159
Memorex	5003,5006,5010,5011,5013 ,5020,5030,5032,5035,504 0,5041,5055,5133,5142,51 43,5145,5146,5151,5155,5 191,5193,5253,5315,5339, 5468

MGA	5006,5010,5030,5034,5052,5151,5152,5155,5167,5193,5257
MGN Technology	5006
Microgenius	5030
Midland	5004,5005,5006,5011,5013,5014,5015,5020,5077,5133,5160,5194,5232,5235
Mintek	5259
Minutz	5008
Mitsubishi	5006,5010,5025,5030,5032,5034,5099,5111,5126,5151,5152,5155,5167,5193,5257,5261,5415,5418,5426
Monivision	5002,5178
Montgomery Ward	5003,5133
Moteva	5191,5344
Motorola	5015,5018,5019,5025,5030,5150,5165
MTC	5006,5010,5011,5013,5020,5021,5024,5041,5042,5049,5127,5151,5152,5155,5159,5230
Multitech	5040,5041,5062
Multivision	5216
Myron&Davis	5306

NAD	5006,5020,5033,5036,5127 ,5151,5155,5286
NEC	5003,5006,5010,5014,5020 ,5031,5035,5037,5059,511 4,5137,5150,5151,5152,51 55,5156,5257,5283,5474
Net TV	5138,5188,5244
Newtech	5020
Nexxtech	5272,5356
Nikei	5184
Nikko	5010,5006,5024,5151,5155
Nikkodo	5006,5010,5024
Niko	5376
Nishi	5005,5010
Norcent	5078,5095,5185,5196
Noshi	5005
NTC	5024,
Nyon	5001
Olevia	5130,5353,5374,5375,5387
Oncommand	5299
Onking	5184
Onwa	5041,5062,5184
Optimus	5003,5006,5010,5011,5013 ,5020,5025,5030,5032,503 5,5036,5041,5047,5063,51 41,5145,5146,5275,5286,
Optoma	5132,5354
Optonica	5025,5035,5165

Orion	5004,5006,5039,5040,5041 ,5046,5055,5142,5177,523 5,5253,5441
Pace	5006,5024
Palsonic	5086
Panasonic (National)	5001,5005,5009,5010,5015 ,5018,5019,5033,5046,504 7,5063,5129,5145,5146,51 50,5194,5207,5275,5276,5 323,5332,5405,5475
Panda	5072
Pausa	5040
Paxonic	5006,5010,5011,5013,5021
PCE	5021,5033,5040
Penney	5001,5002,5003,5005,5006 ,5008,5010,5011,5012,501 3,5014,5015,5020,5021,50 33,5034,5047,5077,5131
Philco	5006,5007,5009,5010,5012 ,5018,5026,5028,5040,504 3,5044,5055,5088,5119,51 50,5151,5152,5155,5157,5 205,5210,5257,5285

Philips	5010,5018,5020,5026,5038 ,5043,5044,5070,5101,5106,5134,5139,5150,5151,5205,5210,5217,5218,5257,5267,5285,5290,5302,5303,5314,5325,5382,5396,5400,5419,5444,5445
Philips Magnavox	5018,5134,5285,5303,5308,5314
Pilot	5006,5010,5013,5015,5020,5021,5151
Pioneer	5012,5019,5036,5066,5151,5155,5219,5282,5283,5286,5424,5487
PIVA	5358
Planar	5339
Polaroid	5081,5110,5173,5252,5278,5284,5348,5371,5468
Portland	5002,5006,5011,5013,5024,5054,5151,5152,5155,5249,
Precision	5039,5041,5042,5046,5049,5271
Price Club	5230
Prima	5030,5080,5087,5094,5238,5270,5272,5348
Princeton	5002,5075
Princeton Graphics	5075,5165
Prism	5015,5019,5047,5194

Proscan	5005,5014,5056,5077,5131 ,5133,5144,5160,5232,526 8,5269,5425
Proton	5002,5006,5013,5054,5056 ,5151,5155,5221,5280,528 7,5342
Protron	5346,5388
Proview	5352,5353
Pulsar	5003,5004,5006,5024,5151 ,5235
Pulser	5006,5024
Quartz	5006,5030
Quasar	5003,5009,5015,5018,5019,5 035,5047,5063,5145,5146,51 50,5194,5207,5275,5276
Rabbit	5014
Radio Shack	5006,5010,5011,5013,5014 ,5020,5030,5032,5035,504 1,5052,5062,5077,5133,51 41,5143,5151,5155,5183,5 184,5190,5191,5275,5309, 5317

RCA	5001,5005,5006,5008,5012 ,5014,5015,5018,5023,5025,5035,5066,5077,5085,5121,5124,5131,5133,5135,5144,5148,5150,5151,5152,5155,5160,5167,5190,5194,5222,5223,5225,5227,5232,5236,5245,5248,5268,5269,5282,5288,5289,5317,5431,5486
Realistic	5002,5003,5006,5010,5011,5013,5014,5020,5030,5032,5035,5041,5052,5062,5133,5151,5155,5183,5184,5190,5191,5275,5309
Replay TV	5484
Rhapsody	5042,5159
Road Authority	5049
Runco	5003,5004,5010,5021,5059,5235,5283
Sampo	5010,5011,5013,5014,5052,5138,5139,5151,5155,5188,5244,5280

Samsung	5004,5006,5010,5011,5013 ,5014,5018,5019,5020,5021,5032,5052,5056,5071,5082,5093,5127,5151,5152,5154,5155,5160,5211,5213,5229,5230,5231,5277,5318,5329,5393,5395,5401,5402,5404,5414,5416
Samsux	5012,5013,5155
Samtron	5230
Sanky	5006,5010,5012,5013,5021,5048
Sansui	5006,5010,5021,5035,5055,5141,5142,5253,5315,5441,5443
Santeca	5294
Sanyo	5001,5014,5018,5022,5029,5032,5034,5038,5052,5055,5089,5118,5138,5151,5191,5224,5233,5234,5407,5412,5430
Saville	5021
Sceptre	5260,5367
Scimitsu	5006
Scotch	5006,5151,5155
Scott	5006,5010,5013,5039,5040,5041,5046,5062,5151,5155,5168,5177,5184,5193

Sears	5001,5003,5004,5005,5006 ,5007,5008,5009,5010,5011,5012,5013,5014,5015,5017,5018,5019,5020,5021,5025,5026,5029,5032,5033,5034,5035,5036,5038,5040,5048,5052,5077,5109,5127,5133,5141,5151,5155,5160,5191,5193,5201,5230,5232,5234,5290,5320,5325
Seimitsu	5006
Selectron	5078,5349,5350
Semp	5333
Sharp	5006,5011,5013,5018,5025,5035,5040,5041,5051,5058,5068,5069,5104,5151,5153,5155,5165,5201,5242,5243,5308,5406,5438,5478
Shengchia	5025
Shivaki	5006
Shogun	5006,5151
Siemens	5011,5028
Signature	5003,5010,5014,5025,5035,5039,5040,5044,5133
Silver	5006
Simpson	5010,5006,5043,5044
Singer	5021,5024
Solardrape	5001,5011
Sole	5092

Sonic	5159
Sony	5001,5004,5017,5030,5032 ,5098,5141,5149,5158,520 8,5319,5391,5394,5397,54 46,5447,5471
Soundesign	5006,5020,5040,5041,5043,5 062,5151,5155,5184,5193
Sova	5335,5360
Soyo	5365,5366,5433
Spectra	5304
Spectravision	5006,5033,5034,5040,5043,5 301
Spectricon	5002,5011
Squareview	5038,5290
SR1740	5032,5038
SSS	5006,5041,5062,5151,5184
Standard Components	5045
Star Sight	5202
Starlite	5006,5041,5046,5062
Sunbrite	5427
Superscan	5025,5109,5201,5325
Supersonic	5330
Supra	5151,5214
Supremacy	5013,5043,5279
Supreme	5001,5149
SV1740	5018
SVA	5078,5110,5306

Sylvania	5001,5006,5007,5009,5010 ,5014,5015,5018,5020,5024,5026,5032,5034,5038,5040,5043,5044,5141,5151,5155,5205,5210,5253,5257,5267,5285,5290,5309,5325,5435
Symphonic	5001,5006,5038,5040,5041,5062,5141,5168,5290,5309,5325
Syntax	5130,5353,5374,5375
Tandy	5013,5025,5035,5045,5165
Tatung	5001,5002,5012,5015,5019,5139,5150,5298
Teac	5029,5032,5034,5049,5069,5072
Technics	5015,5018,5019,5047,5194
Technisat	5488
Technol Ace	5040
Technovox	5010
Techwood	5002,5015,5019,5020,5021,5047,5151,5155,5194
Teknika	5003,5006,5011,5013,5018,5020,5021,5024,5030,5040,5041,5043,5052,5055,5062,5127,5133,5151,5152,5155,5184,5193,5230,5275,5279
Telecaption	5239

Telecolor	5004
Telefunken	5020,5071
Telerent	5133,5003
Teleton	5043
Tera	5151,5287
Tevion	5298
Thomas	5006,5013,5014,5020,5141
Thomson	5014,5133
TMK	5006,5020,5039,5041,5046 ,5151,5155
Tnci	5004
Tocom	5033
Tomashi	5049
Toshiba	5021,5028,5030,5032,5033 ,5035,5036,5052,5063,509 6,5102,5123,5125,5127,51 28,5136,5137,5191,5230,5 239,5241,5257,5275,5283, 5312,5318,5320,5328,5422 ,5440,5473
Tosonic	5042
Totevision	5013,5015
Toyomenka	5006
Truetone	5015,5019,5047
Trutech	5355,5363,5378
TVS	5055
Uher	5006
Ultra	5006,5013,5024
Unitech	5013

Universal	5008,5014,5218
Universum	5011,5029,5037,5039
V	5109,5115,5138,5139
Vidtech	5151,5152,5155
View Sonic	5066,5108,5109,5115,5138,5188,5342,5377,5469
Viking	5279
Viore	5347,5428,5442
Vivtor	5199
Visio	5109,5115,5138,5139
Vizio	5109,5115,5139,5343,5450
Vector Research	5010
Victor	5017
Vidikron	5018
Vidtech	5006
Viking	5021
Wards	5001,5003,5004,5005,5006,5007,5008,5010,5012,5013,5014,5015,5018,5020,5025,5026,5031,5032,5035,5036,5040,5043,5044,5046,5125,5133,5151,5152,5155,5168,5193,5205,5210,5218,5240
Waycon	5033
Welton	5006
Westinghouse	5001,5054,5115,5117,5237,5379

White- Westin ghouse	5040,5046,5054,5055,5061 ,5117,5213,5225,5249,530 9,5340,5470
World	5041,5046,5054,5055
XR 0680	5003,5026,5032,5038,5040 ,5041
Yamaha	5006,5010,5084,5097,5151 ,5152,5155,5275
Yorx	5010
Zenith	5001,5003,5004,5006,5010 ,5013,5014,5024,5025,502 8,5029,5038,5039,5055,50 71,5123,5128,5141,5142,5 151,5155,5180,5181,5192, 5198,5202,5212,5235,5249 ,5250,5253,5262,5308,530 9,5311,5314,5315,5316,53 18,5398
Zonda	5002,5086

TV/DVD COMBOS

BRAND	TV&DVD
Advent	5326
Akai	5410,5361,5362&6294
Apex	5081,(5321)& 6125
Audiovox	5436,5140&6194
Axion	5281&6194
Broksonic	5320
Coby	5359,5364
Changhong	5081,(5321)& 6125

Classic	5081,(5321)& 6125
Daewoo	5256,(5324)& 6159
Diamond vision	5304,(5331),5220&6215,6175
Durabrand	5262&6127
Emerson	5325
Funai	5325
Gpx	5330
Haier	6204
Ilo	5357 ,5362&6294
Initial	5357,5259
Insignia	5325,5173&6182
Jvc	5327
Kawasaki	6047
Konka	5322
Lasonic	5304,(5331)& 6215
Liquidvideo	5281&6194
Magnavox	5325
Memorex	5320
Nexxtech	5356
Panasonic	5323,5332
Philips	5325,5290&6168
Piva	5358
Samsung	5329
Sansui	5320
Sears	5320
Sharp	5201&6122
Sony	5397
Sova	5335,(5360)& 6284

Supersonic	5330
Sylvania	5325,5290&6168
Symphonic	5325
Toshiba	5320,5328
Trutech	5363
westinghouse	5379&6244

STB/SAT/CBL

BRAND	SAT/CABLE/HDTV/SAT DTV WebTV
A Mark	8003,8010
ABC	8002,8003,8014,8048,8049 ,8050,8051,8052
Access	8210
Accuphase	8002
Acorn	8014
Action	8014
Active	8014
Adelphia	8077,8088
Aim	8005
Airlink	8211
Allegro	8016,8056,8097,8098
Alpha Star	8025
Americast	8100
Antronix	8007,8011,8053,8054
Amplica	8138
Apex	8225
Archer	8007,8011,8014,8027,8053 ,8054,8055,8056
Artec	8212

AT&T	8088,8206
BCC	8038
Belcor	8007
Bell Expressvu	8045,8191,8193
Bell South	8100
Betavue	8007
British Telecom	8002
Cabletenna	8007,8053,8055
Cableview	8007
Cablevision	8031
Century	8003,8016,8056,8113
Channel Master	8140,8141,8142
Chapparal	8012,8123,8124
Charter	8207
Cheyenne	8124
Citizen	8016,8056
Clearmaster	8032
Clearmax	8032
Cogeco	8088
Comcast	8088
Comtronics	8058,8059
Contec	8060
Cool Box	8032
Coolmax	8032
Coship	8221
Crossdigital	8034

Curtis Mathes	8005
Digital Music Express	8090
Digital Stream	8220
Director	8038
DirecTV	8018,8021,8023,8024,8028,8034,8035,8039,8040,8042,8043,8044,8046,8063,8109,8110,8111,8139,8153,8172,8178,8179,8181,8184,8185,8196,8199,8201
Dish Network	8041,8045,8148,8149,8191,8193,8204
Dish Network System	8036,8041,8045
Dishpro	8041,8045,8148,8149,8193
Drake	8125,8137,8147
Dreambox	8201
DX Antenna	8131,8144
Eastern	8061
Echosphere	8045
Echostar	8041,8045,8148,8149,8191,8193
Echostar(Dish System)	8013,8022,8036,8041,8045
Emerson	8005,8015,8027
Everquest	8005,8058

Evolutionom	5518
Expressvu	8045,8191,8193
Fortec Star	8118,8119,8120,8121,8122, 8132
Fosgate	8038
Fujitsu	8150,8151
Funai	8039
Garrard	8056
GC Electronics	8011,8054
GE	8006,8010,8018,8085,8104 ,8184,8219
Gemini	8005,8027,8062,8103,8154
General Instrument(GI)	8002,8004,8005,8030,8038 ,8048,8049,8050,8051,808 7,8088,8089,8090,8092,81 01,8127,8128,8129,8152,8 177,8187,8188,8189,8192, 8200
Gibraltar	8002
Globecast	8117,8197
GMI	8032
Go Video	8168
GOI	8045
Gold Star	8010
Goodmind	8027
Hamlin	8005,8048,8063,8064,8065
Hitachi	8002,8003,8024,8028,8049,8 178,8179,8181,8185,8201

Houston	8045
HTS	8045,
Hughes	8181,8201
Hughes Network	8175,8178,8179,8181,8185 ,8201
Hughes Network Systems	8024,8035,8044,8063
Illico	8031
Innova	8111
Insignia	8216
Insight	8038
Jasco	8005,8016,8056
Jerrold	8002,8004,8005,8030,8038 ,8048,8049,8050,8051,808 7,8092,8099
JVC	8036,8041,8045
Kenwood	8157
Legend	8022
LG	8040,8181,8201
Luxor	8158
Magnavox	8022,8023,8027,8041,8066 ,8139,8186,8224
Mcintosh	8030
Mellenium	8056
Memorex	8001,8022,8023,8068
Mitsubishi	8002,8024,8178,8179,8181 ,8185,8201
Motorola	8029,8030,8038,8049,8050

	,8051,8087,8088,8089,8092,8099,8101,8174,8192,8200,5505
Motorola	8205
Comcast	
Movie Time	8067
Multitech	8032
Multivision	8004
Nagra	5507
NET	8114,8165
Netsat	8111
Next Level	8030
Norstat	8160
Nova Vision	8003
Novaplex	8003,8031
Nowtv	8106
NSC	8004,8007,8067
OAK	8015,8060,8069
Optimus	8006,8023
Pace	8003,8014,8029,8031,8170,8171, 8029
Panasonic	8001,8003,8006,8009,8010,8021,8047,8086,8155
Pansat	8145,8198
Paragon	8001,8003,8019,8068
Paysat	8023
Penney	8001
PrimeDTV (PHD)	8057,8105,8159

Philips	8017,8022,8023,8024,8028 ,8035,8041,8044,8045,805 6,8062,8063,8066,8070,80 71,8072,8111,8139,8164,81 75,8178,8179,8181,8185,8 186,8201
Philips Magnavox	8041,8084,8102,8139,8186
Pioneer	8010,8020,8031,8035,8063 ,8073,8074,8163,5510,551 5,5517
Primestar	8030,8177
Prism	8004
Prosat	8126
Proscan	8018,8085,8184
Pulsar	8001,8068
Quasar	8001
Radio Shack	8005,8008,8015,8016,8018 ,8022,8027,8030,8032,804 5,8056,8084,8098,8102,81 62,8215,8227
RCA	8006,8018,8027,8035,8045 ,8047,8056,8063,8085,810 8,8184,8195,8209,8213,82 14
RCN	8088
Realistic	8008,8011,8054,8056,8130 ,8162
Recoton	8056

Regal	8038,8065
Regency	8061
Rembrandt	8007,8049,8056
Rogers	8031
Runco	8001,8068
Samsung	8002,8010,8034,8035,8039 ,8042,8056,8058,8063,807 4,8112,8153,8172
Scientific Atlanta	8001,8002,8003,8004,8006 ,8014,8031,8052,8075,807 6,8077,8226,5511,5512,55 16
Sharp	8163
Shaw	8088
Sierra I II III	8124
Signal	8005,8058
Signature	8049
SKY	8029,8111
Sky Network	8029,8109,8110,8111,8170, 8171,8029
SL Marx	8058
Sony	8033,8043,8146,8161,8196 ,8223
Sprucer	8006,8010,8047
Standard	8078
Star Sight	8085,8182
Star Trak	8091,8166
Starchoice	8030,8177

Starcom	8002,8005,8048,8092
Stargate	8005,8027,8058
Startrak	8025,8030
Starquest	8005
STS	8131,8133,8134
Super Guide	8167
Supercable	8038
Supermax	8032
Sylvania	8143
Tandy	8079
Teleview	8058
Telsat	8113
Texscan	8078
Thomson	8018
Time Warner	8031
Time Warner Cable	8031
Tivo	8035,8063
Tocom	8004,8050,8080,8089,5513 ,5514
Torx	8002
Toshiba	8001,8024,8026,8028,8037,8 044,8068,8135,8176,8178,81 79,8180,8181,8185,8201
Tristar	8032
Tusa	8005
TV86	8067
TVA	8115
Ultimate TV	8018,8043,8184,8196

Uniden	8007,8008,8022,8023,8136 ,8169,8182
Unika	8007,8011,8053,8054,8056,8
United	8156
United Cable	8002,8038,8048
Universal	8007,8011,8016,8053,8054 ,8055,8056,8081,8097
USElectronics	8002,8003,8038
V2	8032
Verizon	5504
Video Cipher ii	8137
Videotron	8031
Videoway	8001,8083
Viewmaster	8032
Viewstar	8059,8066,8067,8079
Vision	8032
Visionetics	8107,5508
Visiontec	8116
Voom	8030
Vortex View	8032
Web TV	8146,8041
Winegard	8217,8218
Zenith	8001,8016,8019,8029,8046 ,8055,8056,8068,8082,809 4,8095,8096,8098,8125,81 37,8147,8154,8173,8183,8 029,8194

Zenith Network	8100
Zinwell	8222

HD TV Set Top Boxes

Access	8210
Airlink	8211
Apex	8225
Artec	8212
Coship	8221
Chaarter	8077
Digital	8220
Directv Models	8175,8199
GE	8219
Go Video	8168
Go Video Hdt100	8168
Hitachi	8181
Hitachi 61hdx98b	8181
Hughes	8181,8201
Hughes Hird E8	8178,8181
Hughes Htl Hd	8178,8181
Insignia	8216
LG	8181,8201
Lg Htl Hd	8178,8181
Lg Lss-3200a	8178,8181

Magnavox	8224
Mitsubishi	8181
Mitsubishi Srhd400	8181
Mitsubishi Srhd500	8181
Mitsubishi Sr-Hd5	8181
Motorola	8174
Motorola hdt100	8174
Philips	8181
Philips dshd800r	8181
Pioneer	8163
Pioneer sh-d505	8163
Proscan	8018
Proscan pshd105	8018
Radio Shack	8215
RCA	8018,8195,8213,8214
Rca hd65w20	8195
Rca dtc-100	8018
Rca dtc-210	8018
Rca pshd105	8018
Samsung	8153
Samsung Sir-T165	8153

Samsung Sir-T351	8153
Samsung Sir-Ts160	8153
Samsung Sir-Ts360	8153
Sony	8196
Sony sathd200	8196
Sony sathd300	8196
Sony sathd100	8196
Sylvania	8143
Sylvania 6900dtd	8143
Toshiba	8181,8201
Toshiba dst3100	8178,8181
Toshiba dw65x91	8178,8181
Toshiba dst3000	8178,8181
Winegard	8217,8218
Zenith	8046, 8222
Zenith dtv108	8046
Zenith hdsat420	8046
Zenith hdsat520	8046

DVD

BRAND	DVD
--------------	------------

3D LAB	6002,6008,6527,6528
Accurian	6023,6024,6034,6039,6047 ,6094,6101,6539
Acesonic	6300
Afreedy	6136
Aiwa	6018
Akai	6025,6027,6055,6120,6151 ,6294,6477
Alba	6021,6029
Allegro	6031,6127,6312,6540
Ames	6147
Amw	6192,6193
Anaba	6223
Anam	6104
Apex	6021,6038,6112,6116,6117,6 125,6140,6146,6152,6154,61 69,6188,6206,6482,6483
Apex Digital	6006,6021,6029,6038,6043 ,6057
Arrgo	6059,6529
Aspire	6202
Aspire Digital	6093
Astar	6282
A-Trend	6118
Audiovox	6023,6029,6065,6071,6072 ,6194
Axion	6023,6065,6194
B&K	6237
Blaupunkt	6029,6146

Blue Parade	6011
Blue Sky	6021,6025,6134,6305
Body Sonic	6136
Bose	6170
Boss	6186
Boston Acoustic	6051 ,6226
Broksonic	6025,6051,6541
California Audio Labs	6001,6531
Cavs	6296
Celestial	6057
Centrex	6021
Centrios	6039,6161,6194,6217,6251 ,6252,6256,6257,6258,625 9,6261
Changhong	6125
Cine Vision	6031,6045,6054,6127
Cinea	6044
Cinego	6091
Citbch	6264
Citizen	6056,6264,6484
Clairtone	6011
Classic	6125,6147,6248
COBY	6021,6068,6070,6173,6191 ,6198,6213,6214 ,6288,629 2,6293,6302
Concept	6146
Conia	6021

CPX	6205
Craig	6044
Creative	6002,6008
Criterion	6160
Curtis Mathes	6521
Curtis International	6198,6199
Cyber Home	6041,6053,6059,6060,6118 ,6207,6242,6523
Cyber Vision	6108
Cytron	6027,6044,6114
Daewoo	6027,6031,6036,6045,6078 ,6080,6081,6155,6156,615 9,6230
Denon	6001,6017,6121,6138,6507
Denzel	6144
Desay	6093
Diamond Vision	6172,6175,6215
Digital Max	6102
Digitrex	6021
Digix	6203
Disney	6022,6086,6168
DiVi Do	6027
Drive	6283
Dual	6022,6044,6064,6067,6144 ,6281
Durabrand	6044,6073,6127,6161,6277 ,6278,6279

DVD 0932	6003
DVD 1710	6126
Eigervision	6297
Electrohome	6056
Elta	6150,6151
Emerson	6022,6031,6042,6127,6168 ,6208
Enterprise	6031
Entivo	6002,6008
Esa	6042,6064
Fahrenheit	6222
Fisher	6135
Funai	6022,6042,6088,6168
Gateway	6077,6210
GE	6004,6029,6040,6130,6146
General Electric	6029
Gold Star	6031,6127
Go Video	6012,6028,6029,6031,6032 ,6035,6045,6066,6069,607 7,6087,6129,6142,6147,61 65,6166,6179,6230,6266
Go Vision	6023,6065
Gradiente	6001,6110,6111,6134
Greenhill	6029,6146
Grundig	6008,6027
Haaz	6030,6163
Haier	6204

Harman/Kardon	6143
Hitachi	6011,6012,6020,6082,6113,6129,6137,6144
Hiteker	6021
HP	6486
Humax	6187
ILO	6089,6221
Infinity	6136
Initial	6029,6146
Insignia	6031,6042,6127,6146,6182,6194,6481,6491
Integra	6011,6014
IRT	6035
JBL	6143
JMB	6025
JVC	6008,6010,6013,6050,6123,6128,6178,6225,6480,6499,6212,6298
Jwin	6116,6172,6174,6291,6534,6536
Kawasaki	6047,6161
Kenwood	6001,6007,6121,6145
Kiss	6144
KLH	6029,6057,6075,6112,6146,6183
Kloss	6006
Konka	6131,6132,6182
Koss	6057,6114,6134

Kxd	6173
Lasonic	6014,6163,6215
Lecson	6099
Lenoxx	6073,6151,6201,6278
Lexicon	6500
LG	6031,6127,6231,6501,6113
Linn	6158
Liteon	6062,6077,6094,6177,6179,6221,6241,6462,6195,6216
Loewe	6031
Logix	6035
Magnasonic	6022
Magnavox	6002,6008,6019,6022,6042,6123,6168,6189,6190,6228,6238,6239,6240,6502,6526,6530,6532,6533,6535
Malata	6249
Marantz	6002,6008,6022,6123,6127,6139,6240
Maxent	6180
McIntosh	6099
Memorex	6025,6044,6086,6247,6299,6474,6506,6514,6519
Meridian	6123
Microsoft	6004,6100,6130
Microvision	6186
Minato	6033
Mintek	6029,6146
Mitsubishi	6003,6098,6126,6485

Mustek	6147
Myron& Davis	6224
NAD	6031,6127,6149
Nakamichi	6148
NEC	6031,6037,6127
Nesa	6029,6146,6224
Nexxtech	6036,6064,6081,6092,6112 ,6161,6203,6219,6251,625 2,6253,6254,6260,6261
Norcent	6056,6070,6197,6198,6241
Onkyo	6002,6014,6123,6234,6509 ,6289
Optimus	6011
Oppo	6505
Orion	6025
Oritron	6134,6257
Pacific	6044
Palsonic	6021
Panasonic	6001,6002,6011,6026,6096 ,6097,6103,6113,6121,622 9,6233,6471,6490,6520,60 90,6280
Philco	6030,6048,6109
Philips	6002,6008,6019,6022,6046 ,6084,6085,6123,6134,613 9,6168,6228,6238,6239,62 40,6285,6306,6489,6119,6 196

Philips Magnavox	6008,6123,6139,6238,6239
Pianodisc	6060
Pioneer	6005,6011,6016,6184,6227,6 235,6236,6275,6503,6167
Polaroid	6057,6068,6112,6220,6303
Polk Audio	6008,6123,6240
Portland	6036,6151
Power Acoustik	6290
Presidian	6022,6023,6102
Proceed	6021
Proline	6134
Proscan	6004,6130,6171
Prosonic	6070
Protron	6197
Pyle	6185
Radio Shack	6011,6105,6106,6161,6164 ,6470
Radionette	6031
RCA	6004,6011,6029,6058,6074 ,6086,6104,6105,6130,613 4,6146,6161,6164,6171,65 22,6262
Realistic	6011
Regent	6201,6277
Reoc	6033,6163
RIO	6031,6127

RJ Technology	6267,6286
Rosen	6200
Rotel	6013,6128
Saba	6106
Sampo	6033,6136
Samsung	6001,6012,6032,6055,6066 ,6129,6165,6166,6287,647 8,6479,6488,6498
Sansui	6025,6226
Sanyo	6022,6025,6052,6088,6135 ,6161,6181,6476
Schneider	6035
Schwaiger	6033
Seg	6144
Selectron	6268,6269,6270,6271,6272 ,6273,6274
Semp	6114
Sensory Science	6077
Sharp	6015,6022,6033,6083,6122 ,6176,6512,6524
Sherwood	6141,6510
Shinco	6146
Shinsonic	6006,6029,6146
Slim Art	6036
Sonic Blue	6012,6028,6031,6035,6069

Sony	6006,6049,6095,6099,6115 ,6124,6243,6244,6245,624 6,6473,6487,6537,6538,60 61
Soundstorm	6185,6186
Sova	6072,6284
Sungale	6214,6218
Superscan	6042
SVA	6021,6029,6033
Sylvania	6015,6022,6042 ,6168,651 1,6276
Symphonic	6022,6042,6088 ,6168
Tascam	6128
Teac	6011,6029,6127,6161
Techa Digital	6011
Technics	6001,6026,6121
Techwood	6008,6149,6263
Terapin	6211
Tevion	6030,6044,6064,6114,6160 ,6162,6163
Theta Digital	6011
Thomson	6004
Tiquidvideo	6194
Tivo	6184,6187
Toshiba	6002,6008,6012,6025 ,607 6,6123,6232,6295,6301,63 73,6475,6515,6516,6525,6 542

Tredex	6209
Trutech	6230,6250
TYT	6027
United	6161
Universum	6031
Urban Concepts	6002,6008
US Logic	6029
V	6063,6079
Venturer	6161
Visio	6063,6079
Vizio	6063,6079,6513
Westinghouse	6244
Wharfedale	6136,6157
White Westinghouse	6168
X-Box	6004,6100,6130
Xenius	6114
Yamaha	6001,6008,6009,6155,6238 ,6239,6504
Yamakawa	6144,6153,6255
Zenith	6002,6031,6123,6127
Zeus	6036
Others	6107,6265

Blue-Ray-DVD

HP	6486
Denon	6507
Memorex	6506
Onkyo	6509

Oppo	6505
Panasonic	6490
Philips	6489
Pioneer	6503
Samsung	6488
Sharp	6512
Sherwood	6510
Sony	6487
Sylvania	6511
Toshiba	6515
Vizio	6513
Yamah	6504

HD-DVD

Panasonic	6471
Toshiba	6472

DVD-R

BRAND	DVD
California Audio Labs	6531
COBY	6302
Gateway	6210
Jvc	6212
Liteon	6216
Magnavox	6530
Memorex	6474
Panasonic	6090,6280
Philips	6119,6196
Pioneer	6167
Sony	6473,6061

Toshiba	6542
----------------	-------------

AUX

BRAND	AUX/AUDIO/AMP
ABS	7008
Accurian	7025,7078,7085
Accutek	7085
ADC	7056
Admiral	7041
ADS Tech	7327
Aiwa	7027,7033,7034,7114,7117, 7150,7251,7254,7261,7269
Akai	7032,7055
Alco	7116
Alienware	7008
Allegro	7001
Altec Lansing	7057,7074,7126
Amana	7154
AMC	7077
Anam	7076,7147
Anam National	7058
Apex	7090
Apex Digital	7090,7119
Apple	7079,7151,7320
Apple Ipod	7285
Arcam	7084
Archer	7001
Astro Text	7005
Audiotronic	7084

Audiovox	7116,7126
AUVIO	7314,7315
Bantor	7001
Bionaire	7085
Bose	7059, 7087,7167,7303
Buffalo A&G	7319
Cambridge Soundworks	7137
Capetronic	7056,7061
Carver	7030,7033,7051,7084,7097 ,7239,7306
Casio	7043
Centrios	7263,7295
Centronic	7001
Citizen	7240
Clarinette	7043
Classic	7108
Clatronic	7066
COBY	7092,7115
Creative	7071
Criterion	7121,7172
Curtis	7066,7092
Curtis Mathes	7028,7300
Cyber Power	7008
D-Link	7021,7135,7323

Daewoo	7088
Delphi	7120,7180
Denon	7033,7082,7109,7123,7219 ,7233,7262
DLO	7086
Emerson	7043,7056
Ensient	7328
Epson	7022
Fisher	7030,7044,7051,7066,7161 ,7230,7236
Frigidaire	7106
Garrard	7047,7055,7064
Gateway	7008,7132
GE	7046
GC Electronics	7001
Glory Horse	7092
Go Video	7108,7139
Gold Star	7001,7140,7198
Goodmans	7066
GPX	7064
Grandtec	7342
Hanwah	7063
Harman/Kardon	7097,7220,7234,7306
Hewlett Packard	7007,7008,7322
Hitachi	7161
Holmes	7085

Howard Computers	7008
HP	7007,7008
Hush	7008
Ibuypower	7008
Imerge	7127
Initial	7122
Insignia	7341
Integra	7069,7100,7160
Ipod	7151
Iport	7166,7168
Jebsee	7001
Jensen	7065
JVC	7016,7075,7092,7099,7111, 7164,7209,7229,7235,7301
Kansai	7055
Kawasaki	7116
Kenmore	7140
Kenwood	7030,7042,7048,7049,7102 ,7144,7145,7176,7224,723 2,7242,7244,7277
KLH	7116,7119
Koss	7064,7110,7171
Left coast	7306
LG	7017,7098,7140,7345
Linksys	7008,7014,7334
Lindemann	7316
Liquid Video	7110
Lloyd's	7043

Logitech	7340
LXI	7040,7064
Macro Image Technology	7015
Macsense	7331
Magnavox	7043,7052,7056,7084,7093,7131,7195,7213,7230,7293
Marantz	7084,7093,7097,7127,7178,7238,7306
Marmitek	7036
Mcintosh	7097
Media Center PC	7008
Memorex	7050,7073
Micromega	7084
Microsoft	7008
Mitsubishi	7282
Mind	7008
Modulaire	7043,7296
Motorola	7012,7336
Myhd	7015
Myryad	7084
NAD	7183,7187,7188
Nakamichi	7102
Navipod	7151
NEO	7184
Nexxtech	7024,7092,7203,7208,7243,7263,7270,7295
Netgear	7159,7318,7335,7339

Nikko	7058
Niveus Media	7008
Norcent	7115,7291
Northgate	7008
Nova	7115
NTDE Geniesom	7064
Olive	7329
Omnifi	7146,7332
One For All	7036
Onkyo	7069,7100,7138,7160,7221 ,7227,7228,7287
Optimus	7026,7028,7029,7030,7032 ,7033,7035,7038,7039,704 0,7041,7042,7043,7044,70 45,7047,7055,7056,7060,7 061,7062,7064,7065,7066, 7067,7068,7070,7072,7076 ,7080,7173,7190,7191,719 2,7193,7194,7211,7296,72 97,7300,7305
Orient Power	7064
Oritron	7110
Panasonic	7003,7096,7101,7103,7133 ,7141,7149,7157,7158,721 0,7226,7231,7237,7271,72 72,7286,7294,7313
PC	7308,7309,7310,7311
Penney	7043,7064

Perception Digital	7337
Philco	7107,7116,7143
Philips	7084,7093,7171,7230,7237 ,7238,7239,7306,7321
Pinnacle	7333
Pioneer	7002,7028,7056,7067,7072 ,7081,7113,7129,7249,727 4,7275,7283,7290,7297,73 00,7305
Polaroid	7129
Polk Audio	7097,7120,7306
Proscan	7089
Radio Shack	7001,7024,7038,7040,7046 ,7064,7092,7147,7194,721 1,7222,7273,7274,7275,72 76,7281,7283,7284,7296
RCA	7028,7051,7056,7072,7076 ,7081,7089,7116,7130,714 7,7182,7185,7200,7204,72 12,7241,7274,7275,7278,7 279,7280,7281,7283,7284, 7289,7297,7300,7305
Realistic	7026,7029,7030,7033,7035 ,7038,7039,7040,7041,704 2,7043,7055,7068,7147,72 96,7297,7299
Ricavision	7008
Rio	7170

Roku	7019
Roku Soundbridge	7317
Saba	7134,7288
Samsung	7006,7020, 7099,7128,7325
Sansui	7084
Sanyo	7044,7051,7067,7125,7161 ,7197
Schneider	7052
Scott	7035,7054,7199
Sears	7043
Security System	7036
Sensory Science	7004
Sharp	7002,7042,7095,7174,7177 ,7225
Sharper Image	7066,7092
Sherwood	7038,7077,7132,7152,7222 ,7267,7268
Shinsonic	7122
Sirius	7126,7164
skyfi	7184
SMC	7018,7343
Sonance	7166,7168
Sonic Blue	7139
Sontec	7031

Sony	7008,7010,7013,7027,7034 ,7053,7075,7091,7118,712 4,7142,7148,7153,7155,71 56,7165,7169,7201,7202,7 206,7214,7215,7216,7245, 7246,7247,7248,7255,7292 ,7312,7338,7304,7307
Soundesign	7060
SSI	7135
Stack 9	7008
Stereophonics	7072
Streamzap	7009
Sunfire	7048,7049,7102
Sylvania	7022,7066
Symphonic	7041
Systemax	7008
Tagar Systems	7008
TAO	7184
Teac	7035,7076,7116,7136,7181 ,7223,7264,7265,7266
Technics	7101,7133,7149,7120,7226 ,7231,7237,7271,7272
Techwood	7052,7058,7061
Telemann	7023
Tevion	7172
Thorens	7084
Toshiba	7008,7028,7069,7081
Touch	7008
Universal	7036

Universal X10	7036
Venturer	7070,7116,7189
Victor	7301
View Sonic	7008,7011,7324,7344
Vizio	7004
Voodoo	7008
Waitec	7108
Wards	7028,7030,7197
Wharfedale	7055
Whirlpool	7105
Windmere	7085
X10	7036
XM	7118,7120
XM Radio	7180,7184
Yamaha	7037,7042,7072,7083,7094 ,7104,7112,7162,7163,721 7,7218,7250,7252,7253,72 56,7257,7258,7259,7330,7 298,7302
Yorx	7043
Zenith	7064,7098,7170,7175,7186 ,7191,7196,7197,7198,720 5,7207,7230,7260
ZT Group	7008
Zyxel	7326

END