



PHD-VRX Firmware Upgrade Instructions

Firmware Ver. VRX.243.23.31:

- (1) Make sure USB Flash Stick is formatted with FAT32.
- (2) Unzip firmware file, (PHD_VRX_firmware-VRX_xxx_xx_xx.zip), and copy all files to root directory of USB Flash stick.
- (3) Turn the unit completely off (push left side POWER button and see no LED lights on the front panel).
- (4) Insert USB stick to any PHD-VRX USB port as shown on the picture.
- (5) Turn on the unit by pushing POWER button. Then, push "STANDBY" button on the right side of the front panel.
- (6) Very soon, you should see "UPDATE" displayed on the front panel LED readout to indicate firmware upgrade is in progress.
- (7) Wait for a while until you see "no ch" shown on the front panel LED readout and TV should display the initial set up screen.
- (8) In this point, please remove the USB stick and then recycle the power by completely remove power cord, then power on and repeating step (3) and (5).
- (9) Wait again until you see the initial setup menu shown on TV screen. Then follow step by step procedures to complete unit setup with this new firmware.

